

Checkpoint UTM-1 Edge Password

Written by Administrator

Saturday, 25 June 2011 09:47 - Last Updated Saturday, 25 June 2011 10:12

Reset Password On Checkpoint UTM-1 / VTM-1 Edge X

-Please note that this will erase all passwords and configurations-

To reset the box to defaults, please do the following:

- * Unplug the power cord.
- * Hold the reset button on the back of the box.
- * Plug in the power cord while holding the button until the pwr/sec led is steady red.
- * Leave the reset button for 3 seconds.
- * Press the reset button again for 10 seconds until the pwr/sec led starts blinking red.
- * Reconfigure your box and install certs.