

## Checkpoint UTM-1 Edge Password

Written by Administrator

Saturday, 25 June 2011 09:47 - Last Updated Saturday, 25 June 2011 10:12

---

## Reset Password On Checkpoint UTM-1 / VTM-1 Edge X

*-Please note that this will erase all passwords and configurations-*

**To reset the box to defaults, please do the following:**

- \* Unplug the power cord.
- \* Hold the reset button on the back of the box.
- \* Plug in the power cord while holding the button until the pwr/sec led is steady red.
- \* Leave the reset button for 3 seconds.
- \* Press the reset button again for 10 seconds until the pwr/sec led starts blinking red.
- \* Reconfigure your box and install certs.