

## Cisco Switch Stack - Default Setup

Written by Administrator

Saturday, 16 July 2011 13:45 - Last Updated Wednesday, 20 July 2011 06:34

---

# How to default a once stacked Cisco 3750 to a single switch

You need to provision it as an stand alone switch:

use this command:

Switch-B(config)#switch 1 provision <switch type>

If the switch was number 2 in the stack this command will make it one.

```
Switch1(Config)#switch 3 provision ?
  nme-xd-24es-1s      provision an EtherSwitch SM with 24+1G interfaces
  nme-xd-24es-1s-p   provision an EtherSwitch SM with 24+1G interfaces
  us-c3750-24ts      provision a Catalyst 3750 switch with 24FX+2G
  us-c3750-24p       interfaces
  us-c3750-24p       provision a Catalyst 3750 switch with 24Pur+2G
  us-c3750-24ts      interfaces
  us-c3750-24ts      provision a Catalyst 3750 switch with 24+2G interfaces
  us-c3750-48p       provision a Catalyst 3750 switch with 48Pur+4G
  us-c3750-48ts      interfaces
  us-c3750-48ts      provision a Catalyst 3750 switch with 48+4G interfaces
  us-c3750e-24pd     provision a Catalyst 3750E switch with 24G+2TenG
  us-c3750e-24pd     interfaces
  us-c3750e-24td     provision a Catalyst 3750E switch with 24G+2TenG
  us-c3750e-48pd     provision a Catalyst 3750E switch with 48G+2TenG
  us-c3750e-48pd     interfaces
  us-c3750e-48td     provision a Catalyst 3750E switch with 48G+2TenG
  us-c3750e-48td     interfaces
  us-c3750e-12s      provision a Catalyst 3750 switch with 12G interfaces
  us-c3750e-12s-d    provision a Catalyst 3750 switch with 12G interfaces
  us-c3750e-16td     and DC power supply
  us-c3750e-16td     provision a Catalyst 3750 switch with 16G+1KENPWR
  us-c3750e-24ps     provision a Catalyst 3750 switch with 24Gpur+4G
  us-c3750e-24ps     interfaces
  us-c3750e-24t      provision a Catalyst 3750 switch with 24GTX interfaces
  us-c3750e-24ts     provision a Catalyst 3750 switch with 24GTX+4G
  us-c3750e-24ts     interfaces
  us-c3750e-24ts-1u  provision a Catalyst 3750 switch with 24GTX+4G
  us-c3750e-24ts-1u interfaces
  us-c3750e-24us-25/50 provision a Catalyst 3750 switch with 24Gpur+2G
  us-c3750e-48ps     interfaces + Wireless Controller
  us-c3750e-48ps     provision a Catalyst 3750 switch with 48Gpur +4G
  us-c3750e-48ts     interfaces
  us-c3750e-48ts     provision a Catalyst 3750 switch with 48GTX+4G
  us-c3750e-48ts     interfaces

Switch1(Config)#switch 3 provision
```

## Cisco Switch Stack - Default Setup

Written by Administrator

Saturday, 16 July 2011 13:45 - Last Updated Wednesday, 20 July 2011 06:34

---

There is more to this story...

In order to get a switch back to position 1 you have to complete this in a few steps.

Otherwise you will still see the newly appointed switch 1 and the old position with all ports showing...

```
switch [current stack number] renumber 1
```

Then once you have the switch renumbered do a *sh ip int brief* `<3750(config)#show ip interface brief>`

You will see 24 or 48 ports in both positions. In my case I had a switch 3 and moved to 1 and completing the *sh ip int brief* will show both positions.

Now you can removed the orphan position, in my case I needed to remove position 3 on a 48 port 3750.

```
<3750(config)# no switch 3 provision ws-c3750-48p>  
<3750(config)# exit>  
<3750# write memory >
```

This works.... I originally used the first method however if you try this you will see what I mean about keeping the original switch position.

It will still show ports on the old number and new....

## Cisco Switch Stack - Default Setup

Written by Administrator

Saturday, 16 July 2011 13:45 - Last Updated Wednesday, 20 July 2011 06:34

---

H.